

Material releases wall / ceiling

Heating foil E-ENERGY CARBON FLEECE

Caution: Install E-ENERGY CARBON according to the installation instructions. Only use plastic spatula to press in the heating foil. Avoid kinks and folds. After installing the heating foil, a complete covering layer (filler, plaster system, tile, etc.) of at least 2 mm must be applied. Use recommended products in accordance with the manufacturer's instructions and the generally recognised rules of technology. **TIP:** Check in the manufacturer's instructions when the heating system can be put into operation. In the case of tile coverings, this can take up to 28 days.

Covering / surface layer	Wall coverings, coatings and fillers	
Primer	StoPrim GT	
If required	Mould removal	-
	Compensation	StoLevell In Mineral
	Primer on balance	-
Thermal Decoupling*	StoLevell In Mineral +Sto-Hartschaumplatte Top 32	
Embedding heating foil	StoLevell In Sil	
Primer on levelling coat	StoPrim GT	
Colour coating	StoColor Rapid Ultramatt	
Wall covering + Colour coating	StoTap Coll + StoTap Pro 300 + StoColor Rapid Ultramatt	
Plaster coating	StoPrep In + StoDecosit K / R / MP / SP	

* A professional dew point calculation must be carried out when applying interior heat insulation to exterior walls. The manufacturer's instructions must be observed.